

AIRAID[®]

INTAKE SYSTEMS

300-120 INSTALLATION INSTRUCTIONS 2000-2004 PT CRUISER (Non-Turbo)

Thank you for purchasing the Airaid Intake System. Please read the instruction manual carefully before proceeding with the installation. Contact Airaid @ (800) 498-6951: 8:00 AM - 5:00 PM MST Weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid Intake System was carefully inspected and packaged. Check that no parts are missing, or damaged during shipping. If any parts are missing, contact Airaid. The air filter element is protected from direct exposure to water and debris in its new location. Care should be taken not to drive through deep water. **WATER INGESTION IS THE DRIVERS RESPONSIBILITY!** The air filter is reusable and should be cleaned using the Airaid Filter Tune-Up Kit periodically.

Thank you for selecting Airaid.



FIG#2



I Disconnect the negative battery cable.

II Remove air cleaner lid.

- Loosen the intake tube clamp at the air box lid.
- Unclip air box lid and remove. Leave the base in place.

III Assemble and Install Airaid C.A.D. (Cool Air Dam)

- Assemble the two halves with the supplied #6 hardware. **See Fig#1**
- Position Airaid C.A.D. in place of the original air box lid. Snap in place.
- Connect the intake tube to the Airaid C.A.D.
- Clamp air filter on to adapter.
- Align notches in weather strip to the corners. Press weather strip on to C.A.D.
- Optional. Cut 9" strip out of hood seal to allow for more cold air-to-air box. **See Fig#2**

IV Finishing up.

- Check over your work.
- Check hood clearance before closing.
- Make sure no foreign objects are in the intake path!
- Re-connect the negative battery cable.

Parts List:

720-431	Airaid Premium Filter	1
KIT120FPC	Front Panel	1
KIT120RPC	Rear MAF Panel	1
KITWSTRIP02	Weather Strip 29 1/2"	1
KIT120HP	Hardware Pack	1
- KIT6C31MXPPZ	6/32 Screw	x4
- KIT6CNICPZ	6/32 Nut	x4
- KIT6NWSAPZ	#6 Flat Washer	x4

Tool List:

- 5/16 nut driver OR
Flat blade screwdriver

